



NOTES:

The SP2-CHAS can be mounted into three ways:

- 1) Wood - use the cutout dimensions shown here. Drill the four corner holes using the SP2-CHAS as a guide.
- 2) Sheetrock - use the SP2-MR. Cutout the sheetrock to the dimensions given. Fold the metal tabs on the mud ring around to the rear of the sheetrock. Use sheetrock screws to attach the mudring to the wall. Tap the holes using a 6/32 tap or the self tapping screws provided.
- 3) backbox - Secure a Hoffman A-SE10X8X4 backbox into the wall. The front of the backbox must be flush with the wall. Make sure that the sheetrock comes all the way to the edge of the backbox. The SP-CHAS will only overhang the box by 1/8" on all sides. Using the panel as a guide, drill and tap (6/32) the 4 mounting holes into the backbox steel.

SP CONTROLS INC		
930 LINDEN AVENUE SOUTH SAN FRANCISCO, CA 94080 (650) 392 7880 FAX (650) 392 7881		
INFORMATION SHOWN ON THIS DOCUMENT IS PROPRIETARY AND IS NOT TO BE REPRODUCED WHOLLY OR IN PART WITHOUT THE EXPRESS PERMISSION OF SP CONTROLS, INC.		
UNLESS OTHERWISE SPECIFIED, DIMENSIONS ARE IN INCHES AND TOLERANCES ARE:		
FRACTIONS: ± 1/64"	DECIMAL: .XX ± .015" .XXX ± .005"	ANGLES: ± 1 DEG